
Installing SBC 5000 Series Hardware

Table of Contents

SBC 5000 Series Hardware Installation Overview

- SBC 5000 Series Hardware Platform Specifications
- SBC 5000 Series Field and Customer Replaceable Units
- SBC 5000 Safety and Regulatory Information
- SBC 5000 Series Site Planning and Requirements
- SBC Pre-Installation Checklist

Rack Mounting the SBC 5000 Series Chassis

- Required Tools and Kit Contents
- Connecting Electrostatic Discharge Wrist Strap
- Attaching the Front Bezel
- Attaching Rails and Rack Ears
- 19 Inch 2-Post Rack Installation
- 19 Inch 4-Post Rack Installation
- 23 Inch 2-Post Rack Installation
- 23 Inch 4-Post Rack Installation
- Unmounting SBC 5000 Series Chassis

Connecting SBC 5000 Series Ethernet and Data Cables

Connecting Power to SBC 5000 Series and Powering On

Post Installation Checklist

This guide provides SBC 5000 series hardware (51x0, 52x0) installation details.



The SBC 5400 hardware installation details are listed separately on the page [SBC 5400 Hardware Installation Overview](#).

