
Managing VX Files

This section contains information necessary to configure the VX node using the VXbuilder application.

- [Loading Configuration Data to VXbuilder](#)
- [Using a Configuration Template](#)
- [Transmitting the Configuration](#)
- [Working with Backup Configurations](#)
- [Starting a New Node](#)
- [Restarting a VX Node](#)
- [Managing VX System Files](#)