
GET relay

REST API Method: **GET /rest/relay**

Retrieves configured digital (DS1) relay state on the SBC Edge system.

URL:

<https://192.168.0.111/rest/relay>

HTTP Method

GET

Requires Authentication:

true

Parameters

Name	Required	Values	Description
filter	No	config	The type of filtered information in the response. If no filters are specified, all get applied.