
Getting Started

Table of Contents

First Steps

- First Steps for SBC 5000 and 7000 Series
- First Steps for SBC SWe
- First Steps for SBC SWe Cloud

About SBC Documentation

About SBC Core

- SBC Core Application Architecture
- SBC Software Edition (SWe) Architecture
- SBC SWe Cloud Architecture

Introduction to Cloud Computing

- Downloading Cloud Packages

SBC Core Key Features

SBC Core Functional Differences

Supported SIP Headers

Supported Standards

SBC Module Descriptions

Interoperability - IOT

Copyright and Trademarks

How to Access the SBC

- Logging Into EMA
- Logging Into CLI
- Logging On to EMA in Platform Mode
- Logging Into BMC
- Accessing SOAP API
- Accessing REST API



The documentation wiki contains both publicly available and restricted content. Restricted materials are reserved for Ribbon Customers and Partners with Ribbon Support Portal access.

If you do not have an account, please register as a Ribbon Customer or Channel Partner.

