
DELETE linkmonitor id

REST API Method: DELETE /rest/linkmonitor/{identifier}

Deletes a Link Monitor Configuration entry given a specific ID.

URL:

`https://192.168.0.111/rest/linkmonitor/{identifier}`

HTTP Method

DELETE

Requires Authentication:

true

Parameters

none