

POST emergencysvcconfig

REST API Method: **POST** /rest/emergencysvcconfig

Modifies the emergency service configuration parameters.

URL:

https://192.168.0.111/rest/emergencysvcconfig

HTTP Method

POST

Requires Authentication:

true

Parameters

Parameter Name	Required	Service Affecting	Data Type	Default Value	Possible Values	Description
CallStatusDuration	Yes	No	int	24	Possible values: <ul style="list-style-type: none">• 1 - Minimum• 24 - Maximum	Emergency Call Status Duration in hours and in increments of 1 hour. Value is from 1 to 24. Default value of 24 Hours. Emergency Call information will be present in Emergency Call Status Table for the duration of this setting.
PreemptNonEmergencyCalls	No	No	Enum	1	Possible values: <ul style="list-style-type: none">• 0 - btFalse• 1 - btTrue	Allows enabling or disabling the preemption of non-emergency calls.



Helpful Tip

The POST can contain either only the attributes that are being updated, or the full set of attributes for the resource