
Managing the Skype Lync SBA



Not supported by SBC SWe Lite in this release.

The Skype/ Lync **Survivable Branch Appliance** (SBA) software includes Microsoft Lync Server running on the Windows server hosted on the [Application Solution Module \(ASM\)](#). The SBA is typically installed in a Branch Office and provides basic voice services to branch users during WAN outage.

Preparing for SBA Deployment - First Steps

- Adding the SBA to Active Directory
- Adding the SBA to your Lync 2010 Topology
- Adding the SBA to your Lync 2013 Topology
- Adding the SBA to your Skype for Business 2015
- Verifying and Configuring DNS

Deploying the SBA

Joining the ASM to a Domain

Generate and Import an SBA Certificate

Starting the SBA Services

Applying an SBA Security Template

Installing Cumulative Updates for Lync SBA

Starting and Stopping SBA Services

Importing an SBA Certificate

Exporting an SBA Certificate

Verifying SBA Certificate

Testing a Lync Call

Upgrading the SBA

- Skype for Business - Best Practice Upgrade to Skype for Business 2015 SBA
- Skype for Business - Best Practice Downgrade to Lync 2010 SBA
- Skype for Business - Best Practice Upgrade to Lync 2013 SBA on Windows Server 2012 R2
- Best Practice Downgrade to Lync 2013 SBA for Windows Server 2008R2

