

---

# DELETE sipnatprefixtable id

---

**REST API Method: DELETE /rest/sipnatprefixtable/{identifier}**

Deletes a SIP Qualified NAT Prefix Table given a specific Table ID.

**URL:**

`https://192.168.0.111/rest/sipnatprefixtable/{identifier}`

**HTTP Method**

DELETE

**Requires Authentication:**

true

**Parameters**

*none*