

---

# POST partition - action setactive

---

**REST API Method: POST**

**[/rest/partition/{identifier}?action=setactive](#)**

This resource causes the given system partition to be made the active partition. This is used to switch partitions.



If the action succeeds, this action will cause the SBC Edge system to automatically reboot. This action can only be performed on partitions 2 or 3, since partition 1 is the boot partition.

## **URL:**

<https://192.168.0.111/rest/partition/{identifier}?action=setactive>

## **HTTP Method**

POST

## **Requires Authentication:**

true