
SG_SUARoutingContext_POST

POST - SUARoutingContext

REST API Method: POST

[/api/defSG/SUA/SUAConfiguredASPs/SUAConfiguredASP/\[string:aid_1\]/SUARoutingContext](/api/defSG/SUA/SUAConfiguredASPs/SUAConfiguredASP/[string:aid_1]/SUARoutingContext)

Adds an SUARoutingContext managed object.

URL:

[/api/defSG/SUA/SUAConfiguredASPs/SUAConfiguredASP/\[string:aid_1\]/SUARoutingContext](/api/defSG/SUA/SUAConfiguredASPs/SUAConfiguredASP/[string:aid_1]/SUARoutingContext)

HTTP Method:

POST

Requires Authentication:

true

Description:

Parameter	Description
[string:aid_1]	[SUAConfiguredASP/Type]
Payload(Not necessarily in order)	{"RoutingContext":"value", "RemoteRoutingContext":"value"}

Parameters:

Parameter Name	Required	Create	Read-Only	Data Type	Description
RoutingContext	Yes	Yes	Yes	int32	Routing context. TL1Name: RC
RemoteRoutingContext	No	No	No	RemoteRC	Remote routing context is used to connect a group of configured RCs. An ASP may go active for the group of RCs by sending a single ASP Active message containing only the remote routing context. All notifications and Acks pertaining to any AS in the group will contain the remote routing context. This feature should only be used when the ASP must send a single Routing Context but it needs register for more than one routing key. It can also be used in the case where a routing context is already configured for an AS and the ASP sends a different RC in the ASPAC message. To set the value to UNDEFINED, enter -1. TL1Name: REMOTERC