

---

# Customer Replaceable Units

---

This section provides descriptions of the following Customer Replaceable Units (CRUs), including how to safely insert and remove them.

## **SBC 5000 Series CRUs**

## **SBC 5400 CRUs**

## **SBC 7000 Series CRUs**



Not applicable to SBC Software Edition.

