
GET corefile

REST API Method: **GET /rest/corefile**

Lists the core files present in the SBC Edge.

URL:

<https://192.168.0.111/rest/corefile>

HTTP Method

GET

Requires Authentication:

true

Parameters

Name	Required	Values	Description
filter	No	runtime	The type of filtered information in the response. If no filters are specified, all get applied.