
Installing SBC 5400 Software

This section includes the following topics for installing the SBC 5400 software.

SBC 5400 - Software Installation Overview

SBC 5400 - Creating an IP Plan

SBC 5400 - Configuring the Platform

SBC 5400 - Installing SecureLink for Remote Access

SBC 5400 - Installing Application

SBC 5400 - Re-Installing ConnexIP Operating System



Warning

The SBC Core system is a closed network device. Customer modifications at the Linux level are not allowed or supported. These modifications can cause stability, update and fail-over issues.

Customers should only configure the SBC using the supported interfaces (CLI, REST, EMA, EMS).

