
POST system - action factorydefault

REST API Method: POST /rest/system?action=factorydefault

This action sets the SBC Edge system to factory default configuration.



After this action, node will not be accessible until the SBC Edge is configured again.

URL:

<https://192.168.0.111/rest/system?action=factorydefault>

HTTP Method

POST

Requires Authentication:

true