
SBC Core Software Installation and Upgrade Guide

Table of Contents

Installing SBC 5000 and 7000 Series Software


Installing SBC 5400 Software

Installing SBC SWe on Virtual Platforms

Upgrading SBC Software

Upgrading SBC SWe Cloud Instances

This guide contains details for system administrators responsible for installing, initializing, upgrading and maintaining the SBC Core software.

 The documentation wiki contains both publicly available and restricted content. Restricted materials are reserved for Ribbon Customers and Partners with Ribbon Support Portal access.

If you do not have an account, please register as a Ribbon Customer or Channel Partner.

