

---

## POST ds1channel - action reset

---

**REST API Method: POST**

**[/rest/linecard/{identifier}/telcods1port/{identifier}/ds1channel/{identifier}?action=reset](#)**

This resource resets the DS1 channel.

**URL:**

<https://192.168.0.111/rest/linecard/{identifier}/telcods1port/{identifier}/ds1channel/{identifier}?action=reset>

**HTTP Method**

POST

**Requires Authentication:**

true