
Unmounting SBC 5000 Series Chassis

Perform the steps below to remove the chassis from the equipment rack:

1. Remove power from the chassis.
2. Disconnect all cables from the chassis.
3. Unscrew (2) #10-32X5/16" Flat Head screws securing the Chassis Rack Ears to the Rack Rail Guides.
4. Carefully remove the chassis from the Rack Rail Guides.



Due to the size and weight of the system, never attempt to install the system by yourself.

