
Configuring VX

Configuring VX

- Basic Configuration and Concepts
- Microsoft Unified Communications Quick Start Guide
- Extended Microsoft UC Features Quick Start Guide
- Active Directory Configuration Quick Start Guide
- Enterprise Voice Quick Start Guide
- V.150.1 Device Quick Start Guide
- SIP Trunking Quick Start Guide
- RADIUS Quick Start Guide
- RFC 4040 Clearmode Quick Start
- Upgrading VX
- IPv6 Quick Start Guide

▼ [Click here to expand TOC...](#)

- Basic Configuration and Concepts
 - VX Key Concepts
 - Understanding and Configuring Trunk Groups with VX
 - Configuring Call Routing with VX
 - Configuring SIP-BSP-SIP Call Routing
 - Call Routing Examples
 - Call Routing IP Interface Selection
 - Configuring SNMP
 - Phone Number Matching and Translation
 - Configuring VX Nodes
- Microsoft Unified Communications Quick Start Guide
 - Gathering Unified Communications Network Information
 - Microsoft Unified Messaging Network Topology and Server Configuration
 - Using the VX Configuration Wizard for Microsoft Unified Communications
 - Understanding the VX Call Flow
 - Testing Unified Communications with a SIP Device
 - Mapping Q.850 to SIP Responses
 - Customizing the VX Configuration in a Unified Communications Environment
 - Troubleshooting Microsoft Unified Communication
- Extended Microsoft UC Features Quick Start Guide
 - Extended UC Solution Description
 - Extended UC Installation Prerequisites
 - Obtaining Security Certificates
 - Configuring VX as an OCS Gateway
 - Configuring OCS to Use VX
 - Troubleshooting Extended UC Features
- Active Directory Configuration Quick Start

Guide

- Active Directory Overview
- Installing Active Directory Scripts
- Configuring the VX Active Directory Functions
- Active Directory-Based Call Routing
- Active Directory Troubleshooting
- Enterprise Voice Quick Start Guide
 - Setting Up an Enterprise Voice Node with VXbuilder Configuration Wizard
 - Verifying Ports
 - Making Traditional Voice Calls
 - Making a TDM-to-TDM Call
 - Making a Toll Bypass Call
 - Secure Voice
- V.150.1 Device Quick Start Guide
 - V.150.1 Device Support
 - Configuring V.150.1 Devices in VXbuilder
- SIP Trunking Quick Start Guide
 - SIP Trunking Overview
 - Microsoft Exchange Unified Messaging and SIP
 - Routing of Inbound SIP Calls
 - Configuring SIP Settings
 - Setting Up SIP Subscriber Tables
 - Setting Up SIP Channel Profiles
 - Setting SIP System Messages
 - ISDN Q.850 to SIP Response Mapping
- RADIUS Quick Start Guide
 - Radius Network Scenario
 - Radius Call Flows
 - Radius Attributes
 - Radius Attributes in Requests and Responses
 - Radius Server Behavior
 - Radius Advanced Features
 - Radius Reference Material
- RFC 4040 Clearmode Quick Start
 - Configure VX for Clearmode
- Upgrading VX
 - Performing a VX Software Upgrade
 - Supported Upgrade Paths
- IPv6 Quick Start Guide
 - Overview - How is IPv6 used in the VX900C?
 - IPv6 Configuration