


Voice Announcements Table

View Voice Announcement Table	Select the Telephony > Voice Announcement Tables subdirectory for the VX node and view contents at the Voice Announcement Tables screen.
Add Voice Announcement Table	Insert a new line in the Voice Announcement Tables screen, then double-click the line to present the Edit Voice Announcement Tables dialog box.
Modify Voice Announcement Table	Double-click on a table line in the Voice Announcement Tables screen to present the { }Edit Voice Announcement Tables{ } dialog box.

MLPP Voice Announcements tables are used with BPA, BNEA, ICA, LOC2, UPA, and VCA.



Field	Description
Table #	Voice table ID.
Desc	Your description for this table