


Troubleshooting Tools - Monitor Endpoint Status

Specifies the status of the Monitor Capture Tool (MCT) settings.

On SBC main screen, go to **Troubleshooting > Troubleshooting Tools > Monitor Endpoint Status**. The Monitor Endpoint Status window is displayed.

Figure 1: Troubleshooting Tools - Monitor Endpoint Status



By default only ten entries are displayed in a view. You can choose the number of entries to be displayed under the **Show entries** drop down box.

Click



to expand the window to display more fields.