



























# Feature Modules

 The VX nodes can be loaded with various feature modules. Use this section to reference all modules available for use with VX devices.

 VX plug-in modules are not hot-swappable. Do not remove a VX plug-in module while VX is powered on.

## ***VX Feature Module Platform Support Matrix***

Feature Module	VX900	VX1200	VX1800
STIX-1T1E1/DSP			
STIX-2T1E1/DSP			
STIX-4T1E1/DSP			
STIX-8FXS/DSP			
NET Security Accelerator			
SSI-4-SS7			
BRI			
One-Port Serial			
Four-Port Serial	