

---

# Installing SBC 5000 Series Hardware

---

## Table of Contents

### ***SBC 5000 Series Hardware Installation Overview***

- SBC 5000 Series Hardware Platform Specifications
- SBC 5000 Series Field and Customer Replaceable Units
- SBC 5000 Safety and Regulatory Information
- SBC 5000 Series Site Planning and Requirements
- SBC Pre-Installation Checklist

### ***Rack Mounting the SBC 5000 Series Chassis***

- Required Tools and Kit Contents
- Connecting Electrostatic Discharge Wrist Strap
- Attaching the Front Bezel
- Attaching Rails and Rack Ears
- 19 Inch 2-Post Rack Installation
- 19 Inch 4-Post Rack Installation
- 23 Inch 2-Post Rack Installation
- 23 Inch 4-Post Rack Installation
- Unmounting SBC 5000 Series Chassis

### ***Connecting SBC 5000 Series Ethernet and Data Cables***

### ***Connecting Power to SBC 5000 Series and Powering On***

### ***Post Installation Checklist***

This guide provides SBC 5000 series hardware (51x0, 52x0) installation details.



The SBC 5400 hardware installation details are listed separately on the page [SBC 5400 Hardware Installation Overview](#).

