

Viewing VLAN Counters

i VLAN counters are supported on the Sonus SBC 2000 only at this time.

i VLAN Counter will count VLAN packets entering from all possible ports.

How to View VLAN Counters

To view a VLAN counter:

1. In the WebUI, click the **Settings** tab.
2. In the left navigation pane, go to **Node Interfaces > Bridge > VLAN**.
3. Click the Counters link in the row of the VLAN in which you want to view the counters.

