
SBC Core Installation and Upgrade Guide

Table of Contents

Installing SBC 5000 Series Hardware

Installing SBC 5400 Hardware

Installing SBC 7000 Series Hardware


Installing SBC 5000 and 7000 Series Software

Installing SBC 5400 Software

Installing SBC SWe on Virtual Platforms

Upgrading SBC Software

This guide contains details for system administrators responsible for installing, initializing, upgrading and maintaining the Sonus SBC Core platforms.

 The documentation wiki contains both publicly available and restricted content. Restricted materials are reserved for Sonus Customers and Partners with a Sonus Salesforce account.

If you do not have an account, please register as a Sonus Customer or Channel Partner.

