
Accessing Log Exchange-LX

Log Exchange (LX) is a multipurpose debugging tool that works with the following:

- VX series gateways
- SBC Edge
- SBX 5000/7000 series
- SWe
- GSX
- Microsoft Lync logs

LX is available **free of charge** for all customers and partners with a license agreement.



These instructions pertain to accessing the LX through the WebUI; you can also go directly to [Log Exchange Documentation](#).

Download the LX from the WebUI as follows:

1. Access the WebUI.
2. In the WebUI, click the **Diagnostics** tab.
3. In the left navigation pane, go to **Logs > Download LX**.
4. Click **Download**. Instructions for installing and using LX are displayed.