

---

# Signaling - CLI

---

The following SBC Core Signaling profiles are included in this section.

## **E164 Profile - CLI**

## **NNI Profile - CLI**

## **X-Header Profile - CLI**

## **Access Transfer Profile - CLI**

## **IP Signaling Profile - CLI**

- IP Signaling Profile - H.323 - CLI
- IP Signaling Profile - SIP - CLI

## **ISUP Signaling Profile - CLI**

## **Number Globalization Profile - CLI**

## **SCTP Profile - CLI**

## **Signaling Profile - CLI**

## **Signaling QoS KPI Profile - CLI**

## **SIP Adaptor Profile - CLI**

## **SIP CPC Cause Code Mapping Profiles - CLI**

- CPC to SIP Cause Map Profile - CLI
- Internal SIP Cause Map Profile - CLI
- SIP to CPC Cause Mapping Profile - CLI

## **SIP Filter Profile - CLI**

