

---

## **POST vlan - action resetcounters**

---

REST API Method: [POST /rest/bridge/{identifier}/vlan/{identifier}?action=resetcounters](#)

---

This resource resets the counters on the given VLAN. This is applicable only to the SBC 2000.

### **URL:**

<https://192.168.0.111/rest/bridge/{identifier}/vlan/{identifier}?action=resetcounters>

### **HTTP Method**

POST

### **Requires Authentication:**

true