

# Changing the BMC Password

For security reasons, change the BMC root password using the steps below:

1. Log on to the SBC BMC using the IP address configured in the previous sections.


At the prompt, enter:

Username: root

Password: superuser


The SBC BMC main screen appears.

**Figure 1:** BMC Main Screen



2. Click **Configuration > Users**. The User Management screen is displayed.

**Figure 2:** User Management Screen



3. Select the root user from the user list.
4. Click **Modify User**.


**Figure 3:** Modifying BMC Password

The screenshot shows the Sonus User Management interface. At the top, there is a navigation bar with the Sonus logo and user information: 'root (Administrator)', 'Refresh', 'Print', and 'Logout'. Below this is a menu with 'Dashboard', 'Configuration', 'Remote Control', 'Firmware Update', 'Platform Manager Ports', and 'HELP'. The main heading is 'User Management'. A text block explains that the list shows available users and provides instructions on how to delete, modify, or add users. It also states 'Number of configured users: 1'. A table lists users with columns for UserID, Username, User Access, Network Privilege, SNMP Status, and Email ID. The 'root' user is highlighted in the first row. At the bottom, there are three buttons: 'Add User', 'Modify User' (highlighted with a red box), and 'Delete User'.

UserID	Username	User Access	Network Privilege	SNMP Status	Email ID
2	root	Enabled	Administrator	Disabled	~
3	~	~	~	~	~
4	~	~	~	~	~
5	~	~	~	~	~
6	~	~	~	~	~
7	~	~	~	~	~
8	~	~	~	~	~
9	~	~	~	~	~
10	~	~	~	~	~

5. Select **Change Password** option.
6. Enter a new password in both the **Password** and **Confirm Password** fields.

**Figure 4:** Modify User Screen



7. Click **Modify** to complete the password change.

The new password gets activated for the next BMC login.

