

Changing the BMC Password

For security reasons, change the BMC root password using the steps below:

1. Log on to the SBC BMC using the IP address configured in the previous sections.


At the prompt, enter:

Username: root

Password: superuser


The SBC BMC main screen appears.

Figure 1: BMC Main Screen



2. Click **Configuration > Users**. The User Management screen is displayed.

Figure 2: User Management Screen



3. Select the root user from the user list.
4. Click **Modify User**.


Figure 3: Modifying BMC Password

The screenshot shows the Sonus web interface. At the top left is the Sonus logo. The top navigation bar includes 'root (Administrator)', 'Refresh', 'Print', and 'Logout'. Below this is a secondary navigation bar with 'Dashboard', 'Configuration' (highlighted in yellow), 'Remote Control', 'Firmware Update', 'Platform Manager Ports', and 'HELP'. The main content area is titled 'User Management' and contains a paragraph of instructions. Below the instructions, it states 'Number of configured users: 1'. A table lists users with columns for UserID, Username, User Access, Network Privilege, SNMP Status, and Email ID. The first row shows UserID 2, Username 'root', User Access 'Enabled', Network Privilege 'Administrator', and SNMP Status 'Disabled'. At the bottom right, there are three buttons: 'Add User', 'Modify User' (highlighted with a red box), and 'Delete User'.

UserID	Username	User Access	Network Privilege	SNMP Status	Email ID
2	root	Enabled	Administrator	Disabled	~
3	~	~	~	~	~
4	~	~	~	~	~
5	~	~	~	~	~
6	~	~	~	~	~
7	~	~	~	~	~
8	~	~	~	~	~
9	~	~	~	~	~
10	~	~	~	~	~

5. Select **Change Password** option.
6. Enter a new password in both the **Password** and **Confirm Password** fields.

Figure 4: Modify User Screen



7. Click **Modify** to complete the password change.

The new password gets activated for the next BMC login.

