


# Managing Signaling Groups

Call Routes Tone Tables Action Sets

## Working with Signaling Groups

1. In the WebUI, click the **Settings** tab.
2. In the left navigation pane, go to **Signaling Groups**.



Type	Description	Admin State	Service Status	Display	Primary Key
SIP	Basic Call from sip phone to server	Up	Up	Counters   Channels	1
SIP	Outgoing to SIP phone	Up	Up	Counters   Channels	2
SIP	BSFT SG	Up	Up	Counters   Channels   Subscriber Data	3
SIP	Local SG	Up	Up	Counters   Channels	4
ISDN	T1-1:1	Up	Up	Counters   Historical Usage	10001
ISDN	T1-1:2	Up	Down	Counters   Historical Usage	10002
ISDN	T1-1:3	Up	Down	Counters   Historical Usage	10003

To view an Signaling Group's properties:

1. Click the popup(



) icon next to the entry you want to view.

2. When you are finished, close the window.



**Helpful Tip:** To delete an entry, simply select the checkbox next to the entry you wish delete, then click the Delete (



) icon located at the top of the window.

## Related Documents

Managing ISDN Signaling Groups  
Managing SIP Signaling Groups  
Managing CAS Signaling Groups