


Managing Message Translations

Message Translation Tables aid in the interworking of differing protocols (like ISDN to SIP) by allowing control over how protocol messages are translated when calls are routed. They are useful for interworking with non-standard equipment and for specialized call routing. To use a table created here, select it from the Message Translation Table field in a [Call Routing Table](#) entry.


For more information, see [Message Translation Usage Overview](#).

Working with Message Translation Tables


1. In the WebUI, click the **Settings** tab.
2. In the left navigation pane, go to **Telephony Mapping Tables > Message Translations**.



To view a Message Translation Table's properties:

1. Click the pop-up icon () next to the entry you want to view.
2. When you are finished, close the window.

To modify a Message Translation Table:

1. Click the **expand** () icon next to the entry you wish to modify.
2. Modify the table's **Description** as desired
3. Click **OK**.

To Create a Message Translation Table:

1. Click the **Create** () icon.

Figure 2: Create Message Translation Table



Create Message Translation Table February 14, 2013 15:03:37 ?

Row ID 2

Description

OK

2. Enter a descriptive name in the **Description** text field.
3. Click **OK**.

 To delete an entry, select the checkbox next to the entry and then click the Delete () icon.

Message Translation Usage Overview

Message Translation Reference

Creating and Modifying Entries to Message Translation Tables