

Managing SIP Signaling Groups

In the case of SIP, they specify protocol settings and link to server, media and mapping tables.

Working with SIP Signaling Groups

1. In the WebUI, click the **Settings** tab.
2. In the left navigation pane, go to **Signaling Groups**.
3. From the **Create Signaling Group** drop down box, select **SIP Signaling Group**.

Figure 1: Signaling Group Table

<input type="checkbox"/>	Type	Description	Admin State	Service Status	Display	Primary Key
<input type="checkbox"/>	SIP	OnPrem: CSPOOL		Up	Counters Channels Sessions AD Update	1
<input type="checkbox"/>	SIP	OnPrem: RegTbl		Up	Counters Channels Sessions	2
<input type="checkbox"/>	ISDN	PBX		Up	Counters Historical Usage	10001
<input type="checkbox"/>	CAS	OnPrem: FXS		Up	Counters Historical Usage	20001

To view an SIP Signaling Group's properties:

1. Click the pop-up icon (



) next to the entry you want to view.

2. When you are finished, close the window.

To delete an entry, select the checkbox next to the entry and then click the Delete () icon.

Configuring the SBC Edge for Site Survivability

Creating and Modifying SIP Signaling Groups

- Forked Call Answered Too Soon (Disconnect on Quick Connect)

Outbound Proxy Configuration

Viewing SIP Counters and Channels

Viewing Subscriber Data

Viewing Sessions Data

Enabling AD Update