

# POST ripconfig id

## REST API Method: **POST /rest/ripconfig/{identifier}**

Modifies a RIP configuration on the SBC Edge system. RIP instance name should not be modified. Logical interface name should be provided for configuring RIP protocol on that interface. If multiple interfaces needs to be configured then the interface name should be comma separated.

### URL:

https://192.168.0.111/rest/ripconfig/{identifier}


### HTTP Method

POST

### Requires Authentication:

true

### Parameters

Parameter Name	Required	Service Affecting	Data Type	Default Value	Possible Values	Description
ConfigIEState	No	Yes	Enum	1	Possible values: <ul style="list-style-type: none"><li>0 - esDISABLED</li><li>1 - esENABLED</li></ul>	Specifies the Administrative State of the resource.
RIPInstanceName	Yes	Yes	string	none	16 - Max Length	Specifies RIP Protocol instance.
enableDefaultInfoOriginate	Yes	Yes	Enum	0	Possible values: <ul style="list-style-type: none"><li>0 - btFalse</li><li>1 - btTrue</li></ul>	Specifies whether Default Information Originate is to be enabled or disabled.
ifName	Yes	Yes	string	none	500 - Max Length	Specifies logical interface name configured for particular routing instance name. If multiple interfaces need to be configured then the interface names should be comma separated. <div style="border: 1px solid green; padding: 5px; margin-top: 10px;"> Logical interfaces configured in the system can be obtained by performing a lookup on logicalinterface resource using GET logicalinterface</div>



#### Helpful Tip

The POST can contain either only the attributes that are being updated, or the full set of attributes for the resource