

# POST ethernetport id

## REST API Method: **POST** /rest/ethernetport/{identifier}

Modifies an Ethernet Port given a specific Table ID.

### URL:

https://192.168.0.111/rest/ethernetport/{identifier}

### HTTP Method

POST

### Requires Authentication:

true

### Parameters

Parameter Name	Required	Service Affecting	Data Type	Default Value	Possible Values	Description
ConfigIEState	No	Yes	Enum	1	Possible values: <ul style="list-style-type: none"><li>0 - esDISABLED</li><li>1 - esENABLED</li></ul>	Specifies the Administrative State of the resource.
ifName	Yes	No	string	none	20 - Max Length	Is the name of the port or logical IP interface. This read-only attribute.
ifAlias	No	No	string	none	20 - Max Length	Assigns an alternative name for the interface; typically configured by the SNMP-based Network Manager. This parameter is unique among all the interfaces known to the SNMP Network Manager. The value cannot have whitespace characters.
ifType	No	No	Enum	0	Possible values: <ul style="list-style-type: none"><li>0 - IF_TYPE_ETHERNET</li><li>1 - IF_TYPE_VLAN</li><li>2 - IF_TYPE_QINQ</li><li>3 - IF_TYPE_BONDED</li><li>4 - IF_TYPE_BRIDGE</li></ul>	Specifies the interface type.
ifDescription	No	No	string	none	64 - Max Length	Assigns an operator-friendly description text configured by the operator for future reference. Whitespaces allowed.

<b>ifNetworkingMode</b>	No	No	Enum	0	Possible values: <ul style="list-style-type: none"> <li>0 - IF_NETWORK_MODE_SWITCH</li> <li>1 - IF_NETWORK_MODE_ROUTE</li> </ul>	Specifies if the port is in switched mode or routed mode.
<b>ifFrameType</b>	No	Yes	Enum	0	Possible values: <ul style="list-style-type: none"> <li>0 - IF_FRAME_TYPE_ALL</li> <li>1 - IF_FRAME_TYPE_UNTAGGED</li> <li>2 - IF_FRAME_TYPE_TAGGED</li> </ul>	Specifies the types of frames allowed when in switched mode.
<b>ifDefaultVlan</b>	No	Yes	string	none	8 - Max Length	Specifies the default vlan of the port is member. of format (portname:defaultvlanid) (max= (32:4095))
<b>ifHybridVlan</b>	No	Yes	string	none	256 - Max Length	Specifies the list of vlans be associated with a port in hybrid state. of the format "(port name id:vlanid),(port name id:vlanid),...." Range of vlanid is 1-4095
<b>ipAddressingMode</b>	No	No	Enum	0	Possible values: <ul style="list-style-type: none"> <li>0 - IPV4_ADDR_MODE</li> <li>1 - IPV6_ADDR_MODE</li> <li>2 - IPV4_AND_IPV6</li> </ul>	Specifies the addressing mode. Can be IPv4, IPv6, or both.
<b>ifIpAddrAssignMethod</b>	No	Yes	Enum	0	Possible values: <ul style="list-style-type: none"> <li>0 - IP_ADDRESS_STATIC</li> <li>1 - IP_ADDRESS_DYNAMIC</li> </ul>	Specifies whether IP address assignment is static or dynamic (i.e. via DHCP). If dynamic is specified, certain node-level settings (i.e. DNS servers, DNS servers, and Domain Name) will be configured such that they obtain their values through DHCP. This is achieved by setting useDynamicNetSettings true in the System Management object. In addition to this, statically configured default routes will be removed from the system. If static is specified, and no other interface is using dynamic addressing, the useDynamicNetSettings will be set to false and the node-level network attributes will be set to use the useDynamicNetSettings configured values.
<b>ifIPv4AddressPrimary</b>	Yes	Yes	string	none	16 - Max Length	Specifies the primary IP address for the interface
<b>ifIPv4AddressPrimaryMask</b>	Yes	Yes	string	none	16 - Max Length	Specifies the primary netmask for the interface

<b>ifIPv4ConfigSecondaryEnabled</b>	<b>No</b>	Yes	Enum	0	Possible values: <ul style="list-style-type: none"> <li>• 0 - btFalse</li> <li>• 1 - btTrue</li> </ul>	Determines if the port has secondary IP address configuration. If this field set to <b>Yes</b> , a secondary address and secondary Netmask must be config
<b>ifIPv4AddressSecondary</b>	<b>No</b>	Yes	string	none	16 - Max Length	Specifies the secondary address for the interface
<b>ifIPv4AddressSecondaryMask</b>	<b>No</b>	Yes	string	none	16 - Max Length	Specifies the secondary netmask for the interface
<b>ifIPv6AddressPrimary</b>	<b>Yes</b>	Yes	string	none	45 - Max Length	Specifies the primary IPv6 address for the interface
<b>ifIPv6AddressPrimaryPrefix</b>	<b>No</b>	Yes	int	64	Possible values: <ul style="list-style-type: none"> <li>• 1 - Minimum</li> <li>• 127 - Maximum</li> </ul>	Specifies the primary IPv6 network prefix length for interface.
<b>ifBridgeGroupId</b>	<b>Yes</b>	Yes	int	1	Possible values: <ul style="list-style-type: none"> <li>• 0 - Minimum</li> <li>• 5 - Maximum</li> </ul>	Configures the bridge group that the Ethernet port will part of. If it's a logical interface, it must be 0. If hardware interface, the default should be 1.
<b>ifConfiguredSpeed</b>	<b>No</b>	Yes	Enum	2	Possible values: <ul style="list-style-type: none"> <li>• 0 - IF_SPEED_10</li> <li>• 1 - IF_SPEED_100</li> <li>• 2 - IF_SPEED_1000</li> <li>• 3 - IF_SPEED_AUTO</li> </ul>	Configures autonegotiation or a specific speed for the Ethernet port. The default value should be changed only when absolutely necessary. <ul style="list-style-type: none"> <li>• When <b>AUTO</b> is selected <ul style="list-style-type: none"> <li>- the speed is automatically negotiated by the Ethernet port</li> <li>- the negotiated speed reported under <b>Negotiated Speed</b>.</li> </ul> </li> <li>• When <b>AUTO</b> is not selected <ul style="list-style-type: none"> <li>- the Ethernet speed-auto-negotiation is disabled and the operator must configure a specific speed for Ethernet port. If the configured speed does not match the attached device, the interface becomes unreachable. The node may become unreachable on using the same interface for management.</li> </ul> </li> </ul>

<b>ifConfiguredDuplexity</b>	No	Yes	Enum	2	<p>Possible values:</p> <ul style="list-style-type: none"> <li>• 0 - IF_DUPLEX_HALF</li> <li>• 1 - IF_DUPLEX_FULL</li> <li>• 2 - IF_DUPLEX_AUTO</li> </ul>	<p>Configures auto-negotiation or a specific value for the duplexity of the Ethernet port. The default value should be changed only when absolutely necessary.</p> <ul style="list-style-type: none"> <li>• When <b>AUTO</b> is selected <ul style="list-style-type: none"> <li>- the duplexity is automatically negotiated by the Ethernet port. The negotiated duplexity is reported under <b>Configured Duplexity</b>.</li> </ul> </li> <li>• When <b>AUTO</b> is not selected <ul style="list-style-type: none"> <li>- the Ethernet duplexity must be explicitly configured. If the configured duplexity does not match the attached device, the interface will become unreachable. The interface may become unreachable on using the same interface for management.</li> </ul> </li> </ul>
<b>ifIPv4ConfigPrimaryEnabled</b>	No	No	Enum	1	<p>Possible values:</p> <ul style="list-style-type: none"> <li>• 0 - IF_PRIMARY_IP_NOT_CONFIGURED</li> <li>• 1 - IF_PRIMARY_IP_CONFIGURED</li> </ul>	Specifies whether the primary IP address is enabled or not.
<b>OSPFDeadInterval</b>	No	Yes	int	40	<p>Possible values:</p> <ul style="list-style-type: none"> <li>• 10 - Minimum</li> <li>• 600 - Maximum</li> </ul>	Specifies the time interval in seconds during which no hello packets are received and after which a neighbor is declared dead.
<b>OSPFHelloInterval</b>	No	Yes	int	10	<p>Possible values:</p> <ul style="list-style-type: none"> <li>• 10 - Minimum</li> <li>• 600 - Maximum</li> </ul>	Specifies the time interval in seconds between hello packets.
<b>OSPFPriority</b>	No	Yes	int	1	<p>Possible values:</p> <ul style="list-style-type: none"> <li>• 0 - Minimum</li> <li>• 255 - Maximum</li> </ul>	Specifies the router priority to determine the DR (designated router) for the network.
<b>OSPFCost</b>	No	Yes	int	1	<p>Possible values:</p> <ul style="list-style-type: none"> <li>• 1 - Minimum</li> <li>• 600 - Maximum</li> </ul>	Specifies the cost of the link-state metric in a router-LSA.
<b>OSPFRetransmitInterval</b>	No	Yes	int	5	<p>Possible values:</p> <ul style="list-style-type: none"> <li>• 5 - Minimum</li> <li>• 600 - Maximum</li> </ul>	Specifies the time in seconds between link-state advertisement (LSA) retransmissions for adjacencies belonging to the interface.

<b>OSPFResyncTimeout</b>	No	Yes	int	40	<p>Possible values:</p> <ul style="list-style-type: none"> <li>• 10 - Minimum</li> <li>• 600 - Maximum</li> </ul>	Specifies the time interval in seconds after which adjacency is reset if out-of-band resynchronization has not occurred. The interval period starts from the time a reset signal is received from a neighbor.
<b>aclInInstanceID</b>	No	Yes	int	0		Specifies the ACL instance applied on this interface for the incoming traffic.
<b>aclOutInstanceID</b>	No	Yes	int	0		Specifies the ACL instance applied on this interface for the outgoing traffic.
<b>aclForwardInstanceID</b>	No	Yes	int	0		Specifies the ACL instance applied on this interface for the forwarding traffic.
<b>ipv6AclInInstanceID</b>	No	Yes	int	0		Specifies the IPv6 ACL instance applied on this interface for the incoming traffic.
<b>ipv6AclOutInstanceID</b>	No	Yes	int	0		Specifies the IPv6 ACL instance applied on this interface for the outgoing traffic.
<b>ipv6AclForwardInstanceID</b>	No	Yes	int	0		Specifies the IPv6 ACL instance applied on this interface for the forwarding traffic.
<b>ifMstpStatus</b>	No	Yes	Enum	0	<p>Possible values:</p> <ul style="list-style-type: none"> <li>• 0 - IF_NOT_REDUNDANT</li> <li>• 1 - IF_MSTP</li> <li>• 2 - IF_FAILOVER</li> <li>• 3 - IF_UNSPECIFIED</li> </ul>	Specifies the MSTP status on this interface. This field is obsolete from release 7.0 onwards and is replaced by 'ifRedundancy'.
<b>ifRedundancy</b>	No	Yes	Enum	3	<p>Possible values:</p> <ul style="list-style-type: none"> <li>• 0 - IF_NOT_REDUNDANT</li> <li>• 1 - IF_MSTP</li> <li>• 2 - IF_FAILOVER</li> <li>• 3 - IF_UNSPECIFIED</li> </ul>	Specifies whether the interface is redundant, and so whether it uses MSTP Failover mode.
<b>gigabitTimingMode</b>	No	No	Enum	0	<p>Possible values:</p> <ul style="list-style-type: none"> <li>• 0 - AUTO</li> <li>• 1 - MASTER</li> <li>• 2 - SLAVE</li> </ul>	Controls gigabit timing mode on the interface. This should be left to "Auto" unless a interoperability issue requires setting the mode to either Slave or Master. This field is only applicable if the configured port speed is either Auto or 1000 mbps.

DHCPSuppliedParamUsage	No	Yes	Enum	0	<p>Possible values:</p> <ul style="list-style-type: none"> <li>• 0 - USE_ALL</li> <li>• 1 - USE_IP_ONLY</li> <li>• 2 - USE_IP_DNS_ONLY</li> </ul>	<p>Determines how the SBC should use the parameters supplied by the DHCP server, when a logical interface is configured with Dynamic IP addressing.</p> <ul style="list-style-type: none"> <li>• <b>USE_ALL</b> - all supported DHCP parameters are used by the SBC. The supplied DNS servers are used as global DNS servers replacing the ones already configured. Split-DNS settings are not affected.</li> <li>• <b>USE_IP_ONLY</b> - only the IP address and netmask are used by the SBC. DNS server and other settings are ignored. Split-DNS settings already in place are not affected.</li> <li>• <b>USE_IP_DNS_ONLY</b> - only the IP address, domain-name and DNS server IP addresses are used by the SBC. The supplied domain-name and the DNS server addresses are used depending on the value of the <b>ConfigureSplitDNS</b> attribute.</li> </ul>
------------------------	----	-----	------	---	---	--

ConfigureSplitDNS	No	Yes	Enum	0	Possible values: <ul style="list-style-type: none"> <li>• 0 - btFalse</li> <li>• 1 - btTrue</li> </ul>	<p>Determines whether the should create split-DNS settings automatically for the DNS and domain name parameters supplied by the DHCP server on this logical IP interface. This field is only if <b>DHCP</b>SuppliedParametersUsage is set to the value "USE_IP_DNS_ONLY".</p> <ul style="list-style-type: none"> <li>• <b>TRUE</b> - SBC configures split-DNS settings by adding one row for each combination of the domain-name and the DNS-server, from the lists supplied by the DHCP server. When the DHCP-lease expires, the split-DNS settings are also automatically removed.</li> <li>• <b>FALSE</b> - SBC configures the IP address and netmask for the logical interface and uses the DNS server/domain-name parameters as global settings. Split-DNS settings are not automatically added when a lease is renewed. If any split-DNS settings have been added, they are removed.</li> </ul>
ifRedundantPort	No	No	Enum	0	Possible values: <ul style="list-style-type: none"> <li>• 0 - IF_NONE</li> <li>• 1 - IF_ETHERNET_1</li> <li>• 2 - IF_ETHERNET_2</li> <li>• 3 - IF_ETHERNET_3</li> <li>• 4 - IF_ETHERNET_4</li> </ul>	<p>Selects which Ethernet port is the redundant port. This can only be configured when 'ifMstpStatus' is set to 'Failover'.</p>



**Helpful Tip**

The POST can contain either only the attributes that are being updated, or the full set of attributes for the resource