

## Getting Started

- Installing VX Hardware
- Bootstrap Configuration of VX

## Product Information

- Terms and Conditions
- Introducing the VX Product Suite
- VX Feature Highlights
- VX Release Information
- VX Solution for SIP Trunking
- VX Solution for Microsoft Unified Communications

## VX Applications Reference

- VXbuilder
- VXwatch
- VXgate
- VXscript
- Command Line Interface Reference

## VX Hardware Reference

- VX900C Chassis
- Feature Modules
- Controlling System Power
- Hardware Maintenance
- Power and System Grounding
- System Specifications

## Configuring VX

- Basic Configuration and Concepts
- Microsoft Unified Communications Quick Start Guide
- Extended Microsoft UC Features Quick Start Guide
- Active Directory Configuration Quick Start Guide
- Enterprise Voice Quick Start Guide
- V.150.1 Device Quick Start Guide
- SIP Trunking Quick Start Guide
- RADIUS Quick Start Guide
- RFC 4040 Clearmode Quick Start
- Upgrading VX
- IPv6 Quick Start Guide

▼ [Click here to expand TOC...](#)

- Basic Configuration and Concepts
  - VX Key Concepts
  - Understanding and Configuring Trunk Groups with VX
  - Configuring Call Routing with VX
  - Configuring SIP-BSP-SIP Call Routing
  - Call Routing Examples
  - Call Routing IP Interface Selection
  - Configuring SNMP
  - Phone Number Matching and Translation
  - Configuring VX Nodes

- Microsoft Unified Communications Quick Start Guide
  - Gathering Unified Communications Network Information
  - Microsoft Unified Messaging Network Topology and Server Configuration
  - Using the VX Configuration Wizard for Microsoft Unified Communications
  - Understanding the VX Call Flow
  - Testing Unified Communications with a SIP Device
  - Mapping Q.850 to SIP Responses
  - Customizing the VX Configuration in a Unified Communications Environment
  - Troubleshooting Microsoft Unified Communication
- Extended Microsoft UC Features Quick Start Guide
  - Extended UC Solution Description
  - Extended UC Installation Prerequisites
  - Obtaining Security Certificates
  - Configuring VX as an OCS Gateway
  - Configuring OCS to Use VX
  - Troubleshooting Extended UC Features
- Active Directory Configuration Quick Start Guide
  - Active Directory Overview
  - Installing Active Directory Scripts
  - Configuring the VX Active Directory Functions
  - Active Directory-Based Call Routing
  - Active Directory Troubleshooting
- Enterprise Voice Quick Start Guide
  - Setting Up an Enterprise Voice Node with VXbuilder Configuration Wizard
  - Verifying Ports
  - Making Traditional Voice Calls
  - Making a TDM-to-TDM Call
  - Making a Toll Bypass Call
  - Secure Voice
- V.150.1 Device Quick Start Guide
  - V.150.1 Device Support
  - Configuring V.150.1 Devices in VXbuilder
- SIP Trunking Quick Start Guide
  - SIP Trunking Overview
  - Microsoft Exchange Unified Messaging and SIP
  - Routing of Inbound SIP Calls
  - Configuring SIP Settings
  - Setting Up SIP Subscriber Tables
  - Setting Up SIP Channel Profiles
  - Setting SIP System Messages
  - ISDN Q.850 to SIP Response Mapping
- RADIUS Quick Start Guide
  - Radius Network Scenario
  - Radius Call Flows
  - Radius Attributes
  - Radius Attributes in Requests and Responses
  - Radius Server Behavior
  - Radius Advanced Features
  - Radius Reference Material
- RFC 4040 Clearmode Quick Start
  - Configure VX for Clearmode
- Upgrading VX
  - Performing a VX Software Upgrade
  - Supported Upgrade Paths
- IPv6 Quick Start Guide
  - Overview - How is IPv6 used in the VX900C?

- IPv6 Configuration

[Download this documentation in PDF format](#)