
VX Hardware Reference

VX Hardware Reference

- VX Chassis Types
- Feature Modules
- Controlling System Power
- Hardware Maintenance
- Power and System Grounding
- System Specifications

- VX Chassis Types
 - VX900 Chassis
 - VX900 T1 E1 Cabling Notice
 - VX900C Chassis
 - VX1200 Chassis
 - VX1800 Chassis
- Feature Modules
 - Nodal Controller
 - STIX-1T1E1 DSP
 - STIX-2T1E1 DSP
 - STIX-4T1E1 DSP
 - STIX-8FXS DSP
 - SSI-4-SS7
 - NET Security Accelerator (NSA)
 - BRI Module
 - One-Port Serial
 - Four Port Serial
- Controlling System Power
- Hardware Maintenance
 - VX900 Fan Filter Service
 - Replacing Parts in the VX1200
 - Removing VX1200 from Rack or Cabinet
 - VX1200 Cover Removal and Replacement
 - Installation of VX1200 Rack Ears
 - VX1200 Field Replaceable Units
 - Replacing Parts in the VX1800
 - Forcing System Shutdown of VX1800
 - Removing VX1800 from Rack or Cabinet
 - VX1800 Cover Removal and Replacement
 - Feature Card Configuration Considerations for the VX1800
 - VX1800 Field Replaceable Units
 - VX1800 Work Space Recommendations
- Power and System Grounding
- System Specifications
 - LEDs
 - T1, E1 Interfaces
 - Serial COM Port Signals
 - Ethernet Port Signals
 - Equipment Dimensions and Weights
 - Environmental and Electrical Specifications
 - Communications Interfaces
 - Serial Interface Card Cables Specifications
 - Serial Interface Card Cable Specifications
 - Serial Interface Card RS530 Conversion Cable Specifications
 - Serial Interface Card SCSI-Sub D Cable Connector Specifications
 - Cabling